

Model Name	10GBASE-SR SFP+ Module	Product Specification	401-59021-ID-SP01
Model No.	PN59021-ID		Page 1 of 3

1. Summary

10GBASE-SR SFP+ Module is SFP (Small-Form Pluggable) module to be connected to a Panasonic Switching Hub's SFP+ extension slot.

2. Rated/Environmental Conditions

2-1. Operating Voltage	DC 3.3V
2-2. Power consumption	1.0W max.
2-3. Operating environment	Temperature: 0 - 50°C Humidity: 20 - 80%RH (no condensation)
2-4. Storage environment	Temperature: -20 - 70°C Humidity: 10 - 90%RH (no condensation)
2-5. Standards	IEEE802.3ae 10GBASE-SR INF-8431 Specification for Enhanced Small Form Factor Pluggable Module SFP+ SFF-8742 Diagnostic Monitoring Interface Class 1 Laser Product (EN 60825-1, EN 60825-2) EN 60950-1

3. Form

3-1. External Dimensions	9mm (Height) × 15mm (Width) × 57mm (Depth) (Excluding protruding sections)
3-2. Mass (Weight)	17g

4. Hardware Specifications

4-1. Interface	Fiber port : LC connector (Duplex), 1port Transmitting and receiving network system : IEEE802.3ae 10GBASE-SR Transmission speed : 10Gbps Compatible cable : Multi Mode Fiber cable 50/125 μm, 62.5/125 μm Maximum transmission distance : 300m (50/125 μm/2000MHz·km Fiber) 82m (50/125 μm/500MHz·km Fiber) 66m (50/125 μm/400MHz·km Fiber) 33m (62.5/125 μm/200MHz·km Fiber) 260m (62.5/125 μm/160MHz·km Fiber)
4-2. Optical wavelength	850nm
4-3. Output Optical Power	-7.1dBm min. - -1dBm max.
4-4. Optical Input Power minimum (Sensitivity)	-11.1dBm
4-5. Diagnostic Monitoring Interface	SFF-8472 Diagnostic Monitoring Interface for Optical Transceivers (DMI) Switching Hub that the device has been installed must have a DMI function too. * 1 Refer 6-1. Supported Products.

5. Accessories

5-1. Accessories	(1) Installation Guide : 1 (2) Protection cap of the fiber optic port (Attached to the module) : 1
------------------	---

Date revised	07/03/2015	Panasonic Eco Solutions Networks Co., Ltd.
Date revised		

Model Name	10GBASE-SR SFP+ Module	Product Specification	401-59021-ID-SP01
Model No.	PN59021-ID		Page 2 of 3

6. Supported Products

6-1. Supported Products	<p>Please use in Panasonic Switching Hubs listed below.</p> <table> <tr> <td>Supported Product Name</td> <td>Supported Product Number</td> </tr> <tr> <td>ZEQUO 6400</td> <td>PN36240E-ID (*1 Supported DMI function)</td> </tr> </table> <p>For the latest information about supported product, check our website. *1 DMI: Diagnostic Monitoring Interface</p>	Supported Product Name	Supported Product Number	ZEQUO 6400	PN36240E-ID (*1 Supported DMI function)
Supported Product Name	Supported Product Number				
ZEQUO 6400	PN36240E-ID (*1 Supported DMI function)				

Date revised	07/03/2015	Panasonic Eco Solutions Networks Co., Ltd.
Date revised		

Model Name	10GBASE-SR SFP+ Module	Product Specification	401-59021-ID-SP01
Model No.	PN59021-ID		Page 3 of 3

7. Prohibitions when Using the Product to Guarantee Safety

The manufacturer assumes no responsibility for any problems occurring when the following conditions are not satisfied. Observe the following items when using the product.

- (1) Do not look at the laser light.
Deviation could lead to visual impairment. (Class 1 Laser Product)
- (2) Do not disassemble and/or modify this SFP+ Module.
Deviation could lead to fire, electric shock, and/or equipment failure.
- (3) Handle the SFP+ Module carefully so that fibers or hands may not be injured by its end connected to the Switching Hub or the SFP+ extension slot of the Switching Hub.
- (4) Do not handle this SFP+ Module and connection cables during a thunderstorm.
Deviation could lead to electric shock.
- (5) Do not put foreign objects (such as metal and combustible) into the opening (such as fiber port, case), and/or do not drop them into the inside of the SFP+ Module.
Deviation could lead to fire, electric shock, and/or equipment failure.
- (6) Do not place this SFP+ Module in harsh environment (such as near water, high humid, and/or high dust).
Deviation could lead to fire, electric shock, and/or equipment failure.
- (7) Do not place this SFP+ Module under direct sunlight and/or high temperature.
Deviation could lead to high internal temperature and fire.
- (8) Do not install this SFP+ Module at the location with continuous vibration or strong shock, or at the unstable location.
Deviation could lead to injury and/or equipment failure.
- (9) Do not connect any equipment other than compliance to fiber port.
Deviation could lead to fire, electric shock, and/or equipment failure.
- (10) Do not put this SFP+ Module into fire.
Deviation could lead to explosion and/or fire.

8. Basic Instructions for the Use of This Product

- (1) For inspection and/or repair, consult the retailer.
- (2) Correctly and securely connect the SFP+ Module to the SFP+ extension slot of a Panasonic Switching Hub.
- (3) Check the connector of the fiber optic cable for dirt and dust. If it is dirty, be sure to clean it before connecting it to the fiber optic port.
- (4) When removing this SFP+ Module from the SFP+ extension slot, unlatch the fiber optic cable and remove it from the SFP+ Module. Then pull down the lever of the SFP+ Module to the front, pull out the SFP+ Module in a state where its latch is released.
- (5) Remove the SFP+ Module from the SFP+ extension slot before cleaning the SFP+ Module.
- (6) Do not touch the metal terminal or place electrically-charged objects in the proximity of the SFP+ Module.
Static electricity could lead to breakdown.
- (7) Please use the SFP+ Module in locations where the ambient temperature is from 0 to 50°C.
- (8) Do not use the SFP+ Module in any condition where the specification limits are exceeded.
Deviation could lead to equipment failure.

Date revised	07/03/2015	Panasonic Eco Solutions Networks Co., Ltd.
Date revised		